PARTS LIST

for



30" ELECTRONIC RANGE COMBINATION EYE LEVEL MICROWAVE AND SELF CLEAN LOWER OVEN

MODEL RM978BXVW1

▲W-White, N-Almond M-Platinum and F-Toast




FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



Whirlpool corporation

Benton Harbor, Michigan.
© 1989 WHIRLPOOL CORPATION

COOKTOP PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

NOTE: the screws and nuts required to attach a part are listed immediately following that part.

```
1
     3171148
                latch, lock
     343641
                screw, 10-16 \times 1/2 (2)
2.
     308185
                switch, safety
                screw (2)
     98106
3
                insulator, switch
     309245
                shield, terminal
4
     313035
     309258
                screw, 6 \times 3/8B (2)
5
     3147065
                handle, latch
                screw, 8-18 \times 1/2
     313349
6
     3148684
                knob, latch
7
     3149194
                box, burner
                screw, 10A \times 3/8 (4)
     309112
                shield, wiring
8
     307973
     343641
                screw, 10-16 \times 1/2 (2)
9
     3148659
                rod, support (2)
10
                switch, lock
     3148669
     313489
                            (2)
                screw
     307965
                bracket
                            (2)
11
                screw, 10-16 \times 1/2 (4)
     343641
                pin, cooktop (2)
12
     307966
     343641
                screw, 10-16 \times 1/2 (4)
13
                cooktop
     3170981
                white
     3170982
                almond
                platinum
     3170984
     3170983
                toast
14
     3147864
                insulator, switch
15
     308604
                stain relief
     246132
                screw, 8A \times 3/8
16
     312606
                receptacle clip (4)
     313808
                screw, 6-32 \times 1/4 (4)
                panel, rear cooktop
17
     3148975
     343641
                screw (4)
18
                pan, reflector
     3148357
                      (2)
     3148358
                8"
                      (2)
19
                element, surface
     660529
                б"
                     (2)
                (alt.)
     309192
     313967
                (alt.)
     660533
                8"
                    (2)
                (alt.)
     309340
     313963
                (alt.)
                (includes illus. 20)
```

```
20 309195 medallion (4)
23 313570 clamp, tube
24 3148790 clip, hold down (4)
25 3148789 rivet (4)
```

following parts not illustrated

note: the termination used on a harness will follow that part.


3149254 harness, surface elements

330031 receptacle (4)

309406 housing, connector 310222 connector, pin (8)

OVEN PARTS

For Model: RM978BXVW1



note: the screws and nuts required to attach a part are listed immediately following that part.

```
1
                   main chassis
      330086
                   white
      330090
                   almond
      330092
                   platinum
      330091
                   toast
                   screw, 10-16 \times 1/2 (2)
      343641
                   screw, 10-32 \times 1/2 (2)
      690989
2
      238614
                   bumper, cooktop (2)
3
      312701
                   leg leveling (4)
4
      3170856
                   frame, front
      343641
                   screw, 10-16 \times 1/2 (13)
5
      307985
                   pin, hinge (2)
6
      309111
                   snubber, door (2)
7
      308306
                   pushnut (2)
8
      327890
                   hinge, r.h.
                   hinge, l.h.
      327891
      343641
                   screw, 10-16 \times 1/2 (4)
9
      329002
                   oven (30" pyro)
      311056
                   screw (3)
10
      660556
                   socket, lamp
                   307856 (alt.)
                   310208 (alt.)
      308043
                   screw, 10-12 \times 7/8 (2)
11
      311255
                   bulb, oven light
      308039
                   cover, light
12
13
      308038
                   retainer, light
14
                   switch, broil
      314209
      314215
                   screw, no. 6
      314210
                   switch, bake
15
      314215
                   screw, no. 6
16
      329710
                   channel, arm (2)
17
      257314
                   plug, button
18
      311220
                   bracket, oven mounting
                   screw, 10-16 \times 1/2 (4)
      343641
19
      307961
                   vent, oven
      307748
                   screw, 10A \times 1/2 (2)
20
      313382
                   clip, therm bulb (2)
      307986
                   hinge pin (2)
21
22
      307594
                   ring, retainer (2)
2.3
      308127
                   spring, door (2)
                   anchor, spring (2)
2.4
      308125
25
      310345
                   switch, door
27
      3148284
                   seal, door
28
      307972
                   cover, service
      343641
                   screw (4)
30
      3147490
                   cover, rear
      343641
                   screw (4)
33
                   ballast
      660001
      346772
                   (alt.)
      685591
                   (alt.)
      343641
                   screw, 10-16 \times 1/2 (2)
34
      308173
                   rack, oven (straight)
35
      258171
                   rack, broiler
36
      310976
                   pan, broiler
```


```
37
      308172
                  rack, oven (offset)
38
      660579
                  element, broil
      311714
                  (alt.)
      311713
                  (alt.)
      266127
                  screw (2)
39
      661170
                  element, bake
      308180
                  (alt.)
      313827
                  (alt.)
                  screw (2)
      246127
                  block, terminal
40
      258076
      98884
                  screw (2)
      112432
                  nut
                       (2)
41
      307970
                  bracket, terminal
      343641
                  screw (2)
      308498
42
                  terminal, ground
      690989
                  screw
      313660
                  clip
                  cover, plate
43
      311982
      307748
                  screw (2)
44
      308127
                  spring, door (2)
```

following parts not illustrated

the termination used on a wiring harness will follow that part.

3149579 harness, main oven 309408 block, disconnect 309407 connector, pin

DOOR PARTS




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

note: the screws and nuts required to attach a part are listed immediately following that part.

```
liner, door
1
      3170707
      3148443
                  screw (4)
2
      307981
                  bracket, rail (2)
      307981
                  screw (4)
3
      3149257
                  glide, front (2)
                  screw (2)
      343641
                  rail, drawer
4
      3149255
                  r.h.
      3149256
                  l.h.
      307748
                  screw (2)
6
      3148160
                  retainer, insulation
      3148443
                  screw (4)
9
      3148182
                  bumper (4)
10
      3148186
                  glass, panel
12
      3148228
                  handle, door
      355515
                  screw (4)
14
      3148223
                  trim, top
      307748
                  screw (3)
15
      3148282
                  clip, mtg. (2)
19
      3148235
                  frame, panel
20
      307980
                  glide, rear (2)
      307748
                  screw (2)
21
                  panel, drawer
      307935
                  white
      307939
                  almond
      313172
                  platinum
      313171
                  toast
      312566
                  screw (3)
22
      313337
                  handle, drawer
      313349
                  screw (2)
26
      357645
                  rack, literature
27
      327887
                  drawer, utility
28
      309329
                  protector, drawer slide (2)
```

CONTROL PANEL PARTS



the screws and nuts required to attach a part are listed immediately following that part.

```
3148090
                   frame, control panel
                   module, control
      3147942
                   screw, 8-32 \times 3/16 (6)
      313818
3
      3147280
                   bracket, control (mounting)
                   screw, 8-32 \times 3/16 (4)
      313818
4
      3147032
                   skirt, dial (4)
5
      3148930
                   thermostat
      311932
                   screw, 6-32 \times 1/4 (2)
6
      3147234
                   switch selctor
                   screw, 8-32 \times 3/16 (2)
      308119
7
      308477
                   switch, infinite (4)
      308119
                   screw, 8-32 \times 3/16 (8)
8
                   light, indicator (3)
      3147862
9
      3147030
                   knob, control (4)
10
      3147888
                   knob, selector (2)
11
      3149036
                   light, indicator
```


following parts not illustated

the termination used on a harness will follow that part.

```
harness, control
3147560
3147218
           socket
308565
           housing, connector
308564
           connector, pin (12)
           key, polarizing (used to install pin into housing)
308563
3147554
           harness, main electronic
311575
           housing, connector
310223
           connector, pin (6)
           harness, infinite switch
3147549
309409
           housing, connector
309407
           connector, pin (8)
3147917
           harness, selector thermostat
309405
           housing, connector
           connector, pin (12)
310222
```

CABINET AND LATCH PARTS


For Model: RM978BXVW1



```
1
      311354
                   bracket, catch includes 3, no. 19
2
      311795
                   catch (2)
      661146
                   switch, primary interlock
4
      313077
                   (alt.)
      313125
                   (alt.)
5
                   screw 4-40 \times 3/4 (8)
      312717
                   shelf, glass install with:
6
      313639
      482338
                   silatic
7
      313126
                   insulator
8
      661144
                   switch, monitor/oven light
      313075
                   (alt.)
                   (alt.)
      313123
9
                   trim, shelf
      313614
                   front
      313615
                   rear
      661145
                   switch, monitor/oven light
10
      313076
                   (alt.)
      313124
                   (alt.)
11
      310211
                   screw 4-40 \times 1 (2)
12
      3149297
                   grille, air
13
      313120
                   switch, electronic
14
      309080
                   screw 8-32 \times 3/8
15
      3149443
                   screw, 6-20 \times 1/2 (3)
                   shield
16
      311360
17
      313663
                   rack, wire
18
      313653
                   support, rack (4)
19
      311928
                   rivet, pop (6)
20
      661146
                   switch, secondary interlock
      313077
                   (alt.)
      313125
                   (alt.)
21
      313598
                   trim, lower
22
      330451
                   door, inner
23
      3170439
                   frame, door
25
      329066
                   latch, complete
26
      311352
                   spring, torsion (2)
27
      313527
                   probe, temperature
                   screw 8-32 \times 5/16 (2)
28
      313811
                   screw (2)
29
      313820
31
      3148296
                   end
                         cap
34
      311777
                   screw 8-32 \times .29 (4)
35
                   handle, door
      313610
37
      313611
                   button, door handle
38
      310197
                   spring, compression
following parts not illustrated
      3147554
                   harness, main electronic
      311575
                   housing, connector
      310223
                   connector, pin (6)
lierature and optional parts
                   wire, 25' roll 12 ga. 150oc
      242828
                   black
      242829
                   red
                   wire, 14 ga. 150oc
      242820
                   black
      242821
                   blue
      242822
                   brown
```

```
242823
                  green
      242824
                  orange
      242825
                  red
      242826
                  white
      242827
                  yellow
                  wire, 14 ga. 200 oc
      242830
                  brown
      242831
                  red
                  yellow
      242832
                  paint, 1/2 oz. touch-up
      72032
                  black
      72017
                  white
                  almond
      72107
      72110
                  harvest gold
      72112
                  toast
      72113
                  platinum
      261869
                  citrine white (microwave)
      254323
                  touch-up oven
      511873
                  white porcelain (2 oz.)
                  paint, 13 oz. spray
      206922
                  primer, white
      206925
                  leveler, enamel
      261890
                  harvest gold
                  almond
      350956
      285365
                  toast
      285366
                  platinum
      799339
                  black
      799343
                  white
      261900
                  citrine white (5 oz.)
                  paint, 1 qt. bulk
                  black (uncut)
      799340
      799344
                  white (uncut)
      261891
                  harvest gold (uncut)
      978883
                  almond (uncut)
      285367
                  toast (uncut)
      285368
                  platinum (uncut)
                  insulation, fiberglass (1-1/2" x 24" x 120")
      261514
                  insulation, fibergalss (2-1/2" x 22" x 120")
      240132
      261582
                  grease
      482338
                  sealer, silistic (3 oz.)
      591014
                  adhesive, loctite (1/3 oz.)
      309551
                  line, splice (5)
      799832
                  kit, porcelain repair (white)
      242985
                  rotisserie kit
      814023
                  non-vent kit
literature parts
      lit3149022 tech sheet
      lit3147391 installation instructions
      lit312903
                 use & care guide
                 use and care guide (microwave)
      lit312902
      lit311895
                 cookbook (microwave)
      lit313358
                  book, cooking guide
      lit884405
                 list, repair parts
```


MICROWAVE ELECTRICAL PARTS



note: the screws and nuts required to attach a parts are listed immediately following that part.

```
3147272
                  transformer
4
      312185
                   screw, 10-32 \times 1/2 (4)
5
      312619
                  bracket, capacitor
8
      661004
                  capacitor
      312631
                  (alt.)
      312632
                  (alt.)
11
      314121
                  fuseblock
15
      313830
                  rectifier, high voltage
16
      312713
                  screw, 8-32 \times 3/8 (2)
      309796
                  fuse (20 amp)
2.2
      313578
                  air duct (horizontal)
23
26
      660595
                  magnetron
      311992
                  (alt.)
      311993
                  (alt.)
      311994
                   (alt.)
      311995
                   (alt.)
      313034
                   (alt.)
28
      661165
                  thermal protector
      312800
                  (alt.)
      313521
                  (alt.)
34
      346893
                  screw, 11-16 x 1/2 double load space thread (2)
36
      313641
                  transmotor
37
      311922
                  pulley, motor
39
      311999
                  "E"
                         ring
40
      313601
                  bracket, motor
42
      311865
                   screw, 6 \times 8/32 round head cross recess (4)
43
      3147223
                  wheeler, blower
44
      313130
                   jumper, high voltage red (6-5/16")
      309330
                   cable tie (2)
45
46
      3147863
                  high voltage lead, gray 6-3/4" (2)
47
      311311
                  clip
48
      3147262
                  extension, air duct
49
      313855
                  fuse, thermal
50
      312713
                  screw
                  socket
51
      330514
52
      661969
                  bulb
53
      661209
                  jack, probe
54
      313105
                  washer
55
      313104
                  nut
```

STIRRER DRIVE PARTS



```
2
      3147004
                  cover, side
                  screw, 8-18 \times .50 (4)
      313638
7
                  screw, 8-32 \times 3/8 pan head phillips
      312713
                  bushing, stirrer
      312023
9
      3147599
                  seal, foam
                  shaft, stirrer
10
     312026
     313595
                  stirrer blade
11
12
     312025
                  washer, nylon
     313816
                  screw, 8-32 \times 1/2 (3)
13
                  pulley, stirrer blade
14
      311923
15
      311999
                  "E" ring
                  fastner
      313740
16
                              (4)
                  nut, standard hex 1/4-20
17
      311721
18
      313646
                  belt, drive
     313563
20
                  stirrer cover
23
     313735
                  plate, tuning
24
                  support (4)
      313739
                  baffle, air
29
      3147002
                 fastener
      310423
44
      313855
                 fuse, thermal
```

EYE LEVEL CHASSIS PARTS

notehe screws and nuts required to attach a part are listed immediately following the part.

```
bracket, stop r.h.
      3147486
      3147487
                   bracket, stop 1.h.
                   screw, 10-16 \times 1/2 (6)
      343641
2
      314216
                   panel, bottom
      312783
                   bumper (4)
                   screw, 10-16 \times 1/2 (2)
      343641
      3147593
                   seal, foam
                   clip (4)
3
      3147525
4
      3147606
                   filter, mesh (2)
5
      3147756
                   edge, protector (2)
                   socket, assembly 1.h.
6
      3147244
      3147245
                   socket, assembly r.h.
                   screw, 8A \times 3/8 (2)
      246132
7
      330677
                   support, frame
                   screw, 10-16 \times 1/2 (10)
      343641
8
                   side panel l.h.
      3147143
                   white
      3147145
                   almond
      3147149
                   platinum
      3147147
                   toast
      343641
                   screw, 10-16 \times 1/2 (6)
                   screw, 8A \times 1/2 (2)
      338156
      3147591
                   seal, foam (2)
      3147592
                   seal, foam (2)
                   side panel, r.h.
      3147142
                   white
      3147144
                   almond
      3147148
                   platinum
      3147146
                   toast
9
                   support, upper chassis
      314195
                   r.h.
      314197
                   l.h.
10
      3170318
                   top panel
      313638
                   screw, 8-18 \times .50 (6)
                   panel, backguard
11
      3147589
12
                   socket, flourscent
      3147224
13
      387695
                   starter, flourscent
14
                   end trim r.h.
      314198
                   white
      314199
                   almond
      314201
                   platinum
      314200
                   toast
                   end trim l.h.
      314203
                   white
      314204
                   almond
      314206
                   platinum
      314205
                   toast
      343641
                   screw, 10-16 \times 1/2 (4)
                   screw, 10-12 \times 7/8 (2)
      308043
16
      313320
                   trim, glass (top)
17
      95292
                   lamp, fluorscent
18
      313322
                   glass panel
19
      313321
                   trim, glass (bottom)
      90767
                   screw 8A \times 3/8 (2)
22
      313319
                   trim, end (glass) (2)
```

```
23
      309330
                  cable tie (2)
24
      3147817
                  blower, exhaust
25
      3147798
                  cover, access
                  screw, 8-18 \times .50 (6)
      313638
      3147866
                       (6)
                  nut
26
                  frame, front
      3148682
                  rivet, plastic (2)
      311928
      3147764
                  spirng, vent door (2)
      3147858
                  rivet (2)
                  vent, door
27
      3147712
      3147724
                  screw (2)
28
      3147607
                  filter, aluminum
                  clip (2)
      3147525
29
      3149007
                  handle, vent door
                  screw, 6-32 \times 9/32 (3)
      313808
30
      3170269
                  door, vent
                  switch, rocker (exhaust)
31
      3147265
32
      314134
                  switch, rocker
33
      3147726
                  cover, exhaust
34
      3147843
                  damper
35
      3147250
                  seperator, air
      3147590
                  seal, foam
                  isulator
36
      3148158
                  seal, foam (2)
37
      3147595
38
      3147596
                  seal, foam
39
      3149016
                  seal, foam (4)
```

following parts not illustrated

the termination on a harness will follow that part.

```
3147556
            harness, vent motor
3147362
            housing, connector
96413
            connector, pin (6)
310960
            housing, connector
311223
            connector, pin (4)
3147568
            harness, rocker switch
            housing, connector
3147361
            connector, pin (4)
97452
```